

UPDATES AND ENHANCEMENTS

GAGETRAK VERSION 8.7.0

This document references version 8.7.0 of both GAGetrak Pro and GAGetrak Lite.

Case No.	Category	Description	App. Area
16558	Change or Enhancement	Using the Connection Manager from an application will now automatically restart the application to connect to the new database.	Settings & Configuration
16571	Issue Corrected	Decimals could not be entered in the Test Point Datasheet when using a Formula.	Calibrations
16718	Change or Enhancement	Restored the Procedure Name to Certificate of Calibration reports.	Reports
16970	Issue Corrected	Company Information section of Service Request/Transfer letter was not center aligned.	Reports
17530	Issue Corrected	Calibration attachments could not be viewed when a calibration record had been signed.	Calibrations
17591	Change or Enhancement	Localization Change: Updated NIST No label to Trace No. This field label change supports other global traceability standards organizations i.e., NIST, CNES, NITE and DIN.	Localization (Spanish, Chinese, etc.)
17824	Change or Enhancement	Added the Custodian Type Customer link to Calibrations.	Calibrations
17880	Issue Corrected	Custodians - Certification Attachments were overwritten with a file from another custodian record.	Custodians
17925	Issue Corrected	Reports and labels would display a format string when a date field was left blank. Example: printing a calibration label with a blank Due date; instead of displaying a blank Due field on the label, a text string would be displayed.	Reports
17930	Issue Corrected	Changes to the Nominal/Min/Max values in the Measurements tab in Calibrations were not carried over to the Test Point Datasheet entry.	System Architecture (Code behind, DB, UI)
17943	Change or Enhancement	Updated several machine translations for French Canadian.	Localization (Spanish, Chinese, etc.)
17986	Issue Corrected	List Management: the "Allow user to add..." setting prohibited an administrator from adding new values to managed lists from Settings.	User Interface (UI)
18035	Issue Corrected	For early upgrade customers, Custodian records would be duplicated post upgrade using the Data Utility. This will no longer occur for users upgrading into version 8.7.	Data Utility
18043	Change or Enhancement	Customer Request: Added Disposition column to Gages History tab	Gages
18050	Issue Corrected	MSA Due List did not display or include Gage Information columns.	Dashboard

18056	Issue Corrected	UI/UX issue in which the Test Point Prefill form was too large to access the command buttons on the form and there was no form scroll option.	User Interface (UI)
18065	Change or Enhancement	Added a Delete option in the Connection Manager. This allows unused database connections to be removed.	User Interface (UI)
18068	Issue Corrected	The Activity Work Order Report was not visible.	Activities
18071	Issue Corrected	An issue was identified where gages with blank due dates were appearing on some Due Lists.	Due Listings
18103	Issue Corrected	A Custodian created from Security would default to Custodian Type Supplier instead of Staff.	Security
18116	Error Resolved	An unexpected error was encountered when filtering by Transfer Date, Expected Resolve Date and Condition Name in the Crib Gage Lookup.	Crib
18127	Issue Corrected	An error appeared on the Calibration Work Order Report on the Results and a blank 2nd page appeared.	Reports
18171	Change or Enhancement	Added column filters for List Management grids in Settings -> List Management.	Wish List
18227	Change or Enhancement	Customer Request: Added To Location and Transfer To in the Gages -> History tab under Transfers history group.	Gages
18257	Change or Enhancement	Added rolling backups and confirmation of databases in Data Utility for database upgrades, ensuring additional database upgrade attempts do not overwrite an existing backup.	Data Utility
18259	Issue Corrected	A current security user could be deleted from Security (deleting the a user that is currently logged in is not permitted).	Security
18267	Issue Corrected	Transfer labels were not displaying current record Gage ID.	Crib
18268	Issue Corrected	An Auto number with three letter month and year did not work correctly for the month of May.	Settings & Configuration
18285	Issue Corrected	The Find/Replace tool would hang up when the paging feature was enabled.	Settings and Configuration
18350	Change or Enhancement	Machine translations have been added to support Chinese Traditional, Korean, Malay, Japanese, Thai, Filipino	Localization (Spanish, Chinese, etc.)
18356	Change or Enhancement	Added Embed/Link Requirement Options to Settings. Enhancing the new document embedding and URL linking capabilities in GAGetrak 8.7, this new setting allows administrators in GAGetrak to enforce the attachment options. Example: If an organization wants to only embed file attachments for Calibration records, the other file link options can be eliminated for users.	Settings & Configuration
18361	Issue Corrected	An unexpected error would occur when users tried to archive Transfers and Service Requests.	Archive
18373	Issue Corrected	An issue was found in the Crib and MSA modules where the module would close when a user attempted to run an ad-hoc report.	Crib
18374	Issue Corrected	The Select Report window for canned reports in Crib and MSA modules did not display the available reports.	Reports
18385	Issue Corrected	The Select Report window for canned reports in Procedures did not display the available reports (GAGetrak Lite only).	Procedures

18395	Issue Corrected	The Notification Manager would close when clicking the Send Now button.	Email Notification Manager
18401	Issue Corrected	The GAGetrak application would crash when a user tried to attach files to Quick Access folders in Windows that were not available.	Application
18402	Issue Corrected	Upgrade customers who had single quotes in Calibration -> Results field would encounter an error transferring records to GAGetrak 8. This will no longer occur for customers who upgrade to 8.7 from version 6 or version 7 of GAGetrak.	Data Utility
18442	Issue Corrected	An issue was found where the Comment in test points were populated with the Test Point Name.	Gages
18445	Issue Corrected	Skip Dates were not honored under certain conditions.	Calibrations
18452	Change or Enhancement	(GAGetrak Pro Edition only) - During the database upgrade process from earlier versions of GAGetrak, the Data Utility will now import existing study Characteristics into the Products table. These can then be selected during creation of new MSA studies.	Data Utility
18455	Issue Corrected	Test results were not saved in MSA records for certain conditions.	MSA
18457	Issue Corrected	Data Upgrade: Part No records defined in Gt7 RR studies were not populated or associated with Product records.	Data Utility
18458	Issue Corrected	Upgrade customers had missing Products in listings. The Data Utility was setting all Products migrated from Parts in GAGetrak 7 to Inactive, making them unassignable.	Data Utility
18537	Issue Corrected	The Last Done By value was cloned to new records (this feature should not clone historical data to resultant records).	Gages
18538	Issue Corrected	The scroll bar was missing for users attempting to add Gages to Transfers and Service Requests.	Crib
18561	Error Resolved	Reminders would generate a fatal error when a Reminder record had a blank reminder name.	Gages
18568	Change or Enhancement	Added Fields for MSA Percentages for Study Variation, NDC and Sigma factor.	Settings & Configuration
18615	Issue Corrected	Transfer and Cancel buttons on Transfer Gage form were minimized	Gages
18616	Issue Corrected	Transfer labels were missing all data other than Gage ID.	Crib
18630	Issue Corrected	First gage record was blanked after opening/closing Gages.	Gages
18664	Issue Corrected	Users could not create new calibration records from a filtered/saved View in the Calibration Due List.	Dashboard
18682	Issue Corrected	Users attempting to remove gages from the Frequency Adjustment were not deleted after save.	Frequency Adjustment
18690	Issue Corrected	The Past Due flag was still displayed for gage records with a Status that was not configured to appear in due lists and notifications.	Gages
18691	Issue Corrected	Custodians that were not configured as Assignable were still visible in some lists.	Custodians

18710	Issue Corrected	An issue was reported from upgrade customers that Part numbers from GAGetrak Issue Tracking were not coming over to Products tables in the upgrade to GAGetrak 8. Customers upgrading to 8.7 will not experience this issue.	Data Utility
18712	Error Resolved	Unexpected error when saving a record under Email Reports for Canned Reports.	Email Notification Mgr
18740	Issue Corrected	Users could not delete a Custodian record that had and no associations to historical records.	Custodians
18751	Issue Corrected	Deleting Calibrations with audit log generated exception - ItemName in containers was not always correctly bypassing null navigation items. Added code to gateways to get the parent and/or grandparent object. Added code to subrecords in ContainersPartial to provide ItemFirstIdentifier, etc for records.	FDA
18757	Change or Enhancement	Added clarification in Settings-> List Management as to how sort order in Calibration Signature Levels corresponds to the signature order/level.	Settings & Configuration
18790	Issue Corrected	Activity Work Order report displayed a text box error on second page of the print preview.	Gages
18797	Error Resolved	An unexpected error would occur when opening the History tab in Products entry.	Crib
18849	Issue Corrected	MSA (Attribute, Linearity, Stability) Studies: upon opening in edit mode, the record would require a save action, even though no changes were made for that record.	MSA
18850	Change or Enhancement	Updated the Custom Form View grid column name to "Windows User Name" which eliminates confusion between Custodian User and the Windows User Name for saved view assignment. Saved Views are assigned to the Windows user name so they are not lost if a Custodian User ID changes.	Settings & Configuration
18862	Issue Corrected	Deleting a Gage Type in Managed Lists would generate an exception error.	Settings & Configuration
18864	Issue Corrected	A1/A3 adjusted gages would appear multiple times in the Frequency Adjustment Gages table.	Gages
18866	Issue Corrected	The A3 Frequency Adjustment was not recommending frequency changes in certain cases.	Gages
18883	Issue Corrected	Email notifications from Gage Lookup were not following the filter criteria.	Crib
18884	Issue Corrected	Gage Templates: users were not prompted to save changes and linked gages were not updated as a result.	Gage Template
18893	Issue Corrected	An exception error was discovered when un-checking DueStatus in Due List filters.	Dashboard
18902	Change or Enhancement	Changed field label for Paused Schedules from Use Used and Use Left to Time Used and Time Left. The previous terms created confusion as to the purpose of these two fields.	User Interface (UI)
18903	Change or Enhancement	Added document embedding and URL link in all file attachment options. This provides greater flexibility for file attachments and adds support for linking to Cloud-based file shares such as Microsoft SharePoint.	User Interface (UI)
18905	Issue Corrected	The Gage Lookup Listing report showed a red error box on the report preview.	Crib

18924	Issue Corrected	GAGEtrak Lite users could not see the Calibration Results option in Managed List items.	Settings & Configuration
18930	Error Resolved	An unexpected error occurred when GRR study trial data would exceed the upper spec limit.	MSA
18931	Issue Corrected	Changing number of Trials in MSA Anova studies did not change number of products in the study Measurements tabs.	MSA
18970	Issue Corrected	Cloning a gage with a paused schedule cloned Time Left and Time Used values - Testing of cloning template, cloning gage, creating gage from template and creating template from gages shows that Period Left, Period Used, and Last Paused are not copied from one to another.	Gages
19065	Issue Corrected	In some cases, cloning a Service Request would cause exception errors.	Crib
19077	Issue Corrected	The Custodian Reassignment List was incorrect for GAGEtrak Lite users.	Custodians

Issue corrections made in this update do not reflect a complete list of issues identified in the previous release (to minimize the risk of creating further code issues during the update process, some problems identified may be reserved for correction in a later update). Therefore, if you have reported an issue that you do not see listed here and you received a confirmation from our support team, it will likely be corrected in a future update.

SUPPORT

+1 (480) 212-1257
 1-800-777-7020
support@cybermetrics.com

SALES

+1 (480) 922-7300
 1-800-777-7020
sales@cybermetrics.com

